
ELLIPITICAL, ROUND & OVAL PORTLIGHT

(OIL HYDRAULIC MADE, WITH STORM COVER)



INSTALLATION:

- 1. DIG HOLE PER THE SPECIFICATION FOR CUT OUT SIZE OF PORTLIGHT IN HULL WALL.
- 2. FULL-FILL SEAL COMPOUND IN POSITION "D". OF TRIM RING. OUTSIDE BOAT INSTALL PORTLIGHT TOWARD INSIDE. TO USE "C STYLE CLAMP" FASTEN IT. THEN BEND S/S FIXED STRIP OUTWARD AND SCREW BOLT (B) INTO HULL.
- 3. FULL-FILL SEAL COMPOUND IN THE POSITION "C" OF PORTLIGHT. INSIDE BOAT INSTALL PORTLIGHT TOWARD OUTSIDE, THEN USE"C STYLE CLAMP" FASTEN IT, AFTER SCREW BOLT(A)INTO HULL.